

Limited Pilot Owner/Maintenance

The following constitutes the limited pilot maintenance referred to in Regulation (EC) No.2042/2003 Part M M.A.803 and Appendix VIII provided it does not involve complex maintenance tasks.

1. Removal, installation of wheels.
2. Replacing elastic shock absorber cords on landing gear.
3. Servicing landing gear shock struts by adding oil, air, or both.
4. Servicing landing gear wheel bearings, such as cleaning and greasing.
5. Replacing defective safety wiring or cotter keys.
6. Lubrication not requiring disassembly other than removal of non-structural items such as cover plates, cowlings, and fairings.
7. Making simple fabric patches not requiring rib stitching or the removal of structural parts or control surfaces. In the case of balloons, the making of small fabric repairs to envelopes (as defined in, and in accordance with, the balloon manufacturers' instructions) not requiring load tape repair or replacement.
8. Replenishing hydraulic fluid in the hydraulic reservoir.
9. Refinishing decorative coating of fuselage, balloon baskets, wings tail group surfaces (excluding balanced control surfaces), fairings, cowlings, landing gear, cabin, or cockpit interior when removal or disassembly of any primary structure or operating system is not required.
10. Applying preservative or protective material to components where no disassembly of any primary structure or operating system is involved and where such coating is not prohibited or is not contrary to good practices.
11. Repairing upholstery and decorative furnishings of the cabin, cockpit, or balloon basket interior when the repairing does not require disassembly of any primary structure or operating system or interfere with an operating system or affect the primary structure of the aircraft.
12. Making small simple repairs to fairings, non-structural cover plates, cowlings, and small patches and reinforcements not changing the contour so as to interfere with proper air flow.
13. Replacing side windows where that work does not interfere with the structure or any operating system such as controls, electrical equipment, etc.
14. Replacing safety belts.
15. Replacing seats or seat parts with replacement parts approved for the aircraft, not involving disassembly of any primary structure or operating system.
16. Trouble shooting and repairing broken circuits in landing light wiring circuits.
17. Replacing bulbs, reflectors, and lenses of position and landing lights.
18. Replacing wheels and skis where no weight and balance computation is involved.
19. Replacing any cowling not requiring removal of the propeller or disconnection of flight controls.
20. Replacing or cleaning spark plugs and setting of spark plug gap clearance.
21. Replacing any hose connection except hydraulic connections.
22. Replacing prefabricated fuel lines.

23. Cleaning or replacing fuel and oil strainers or filter elements.
24. Replacing and servicing batteries.
25. Cleaning of balloon burner pilot and main nozzles in accordance with the balloon manufacturer's instructions.
26. Replacement or adjustment of non-structural standard fasteners incidental to operations.
27. The interchange of balloon baskets and burners on envelopes when the basket or burner is designated as interchangeable in the balloon type certificate data and the baskets and burners are specifically designed for quick removal and installation.
28. The installations of anti-misfuelling devices to reduce the diameter of fuel tank filler openings provided the specific device has been made a part of the aircraft type certificate data by the aircraft manufacturer, the aircraft manufacturer has provided instructions for installation of the specific device, and installation does not involve the disassembly of the existing tank filler opening.
29. Removing, checking, and replacing magnetic chip detectors.
30. Removing and replacing self-contained, front instrument panel-mounted navigation and communication devices that employ tray-mounted connectors that connect the unit when the unit is installed into the instrument panel, (excluding automatic flight control systems, transponders, and microwave frequency distance measuring equipment (DME)). The approved unit must be designed to be readily and repeatedly removed and replaced, not require specialist test equipment and pertinent instructions must be provided. Prior to the unit's intended use, an operational check must be performed.
31. Updating self-contained, front instrument panel-mounted Air Traffic Control (ATC) navigational software databases (excluding those of automatic flight control systems, transponders, and microwave frequency distance measuring equipment (DME)) provided no disassembly of the unit is required and pertinent instructions are provided. Prior to the unit's intended use, an operational check must be performed.
32. Replacement of wings and tail surfaces and controls, the attachment of which are designed for assembly immediately before each flight and dismantling after each flight.
33. Replacement of main rotor blades that are designed for removal where specialist tools are not required.